

**PLEASE REFER TO THIS GUIDE FOR CARE AND MAINTENANCE BEST SUITED FOR
SOLSTONE RESILIENT RIGID CORE FLOORING.**

- All spills should be cleaned up immediately. Routinely vacuum, sweep and / or dust floors using standard cleaning equipment.
- Use doormats at entrance ways to protect floor from discoloring and prevent dirt and dust.
- Avoid exposure to direct sunlight for prolonged periods of time. Close blinds or drapes during peak sunlight hours.
- Use floor protectors under stationary furniture and rolling chair legs/feet to distribute weight loads.
- When moving heavy furniture or appliances, lifting them is highly recommended. Attempting to drag heavy items at the minimum, will most likely leave a scuff mark, or worse, tear the floor. If it's too heavy to lift, please try to add a protective layer over the floor such as plywood, carpet or bed sheets and then drag it over to move it. The protective layer helps distribute the weight and reduce denting or scratching.
- **DO NOT** use treated dust mops. For heavier duty cleaning, use a damp mop with clean water or a neutral pH-based cleanser diluted in water. Avoid any cleaners that contain bleach, washing liquid or general cleaning products, unless it has been specified on the bottle that it is suitable for rigid core vinyl flooring. Using incorrect cleaners can damage the flooring, causing discoloration and deterioration of the protective wear layer.
- **DO NOT** use harsh cleaners or chemicals on your flooring. Oil and petroleum based products can result in surface staining.
- **DO NOT** use abrasive scrubbing tools or vacuums with a beater bar.
- **DO NOT** use electric brooms with hard plastic bottoms without padding. Avoid steam cleaners at all costs.